

Part #	Description	Serial #	Condition
33700002	FIRE EXTINGUISHER	18840D1	EXPIRED
33700002	FIRE EXTINGUISHER	20221D1	SV
65-44910-30	ACTUATOR ASSY	TSC2841	ASR
65-44910-30	ACTUATOR ASSY	TSC1682	ASR
65-46141-11	UPLOCK ASSY-MLG LH	2036	ASR
6577-1	FAN-VANEAXIAL	7447	ASR
6577-1	FAN-VANEAXIAL	2439	ASR
2800003-103	VALVE	2557	ASR
65-46370-17	CHANGER ASSY-RATIO	E1661	ASR
R6166M1	ACTUATOR ASSY-ROTARY	850105	ASR
65-44691-5	MODULAR ASSY	3533	ASR
65-44691-6	MODULAR ASSY	1382	ASR
65-49970-25	STAB TRIM ACTUTRASSY	KE0117	ASR
4105DA	CONTROL VALVE	1478	ASR
R1053M18-2	A/P LATERAL CONT	890319	ASR
65-17821-20	MODULAR PACK AY	540	ASR
65-44610-4	NLG HYD.ACTUATOR AS.	ES939	ASR
310A1020-20	FITTING	A20832	ASR
310A1020-20	FITTING	A21133	ASR
65-44981-5	MODULAR PACKAGE AY	1481	ASR
3810056-106	VALVE, T/R CONTROL	02384	ASR
65-17821-20	MODULAR PACK AY	0602	ASR
31040	VALVE, EQUI COOLING	343	ASR
2760000-101	SHUTOFF VALVE	1196	BER
541674-4	RAM AIR ACTUATOR	88-4307	SV
285T0855-1	MODULE ASSY-FLIGHT DECK ACCESS SYSTEM CON.	D05901	ASR
65-44981-5	MODULAR PACKAGE AY	1446	ASR
39-353	CONTROL VALVE	7290	ASR
69-54600-3	CYLINDER ASSY - HYDR TRANSFER MAIN GEAR	DA2273	ASR
1U1065-2	COMPENSATOR	1678	ASR
33007505	CONTAINER FIRE EXT.	38504B1	ASR
10-62008-16	PRECOOLER AIR BLEED	47-3987	ASR
10-62008-16	PRECOOLER AIR BLEED	28-1076	ASR
33007505	CONTAINER FIRE EXT.	385004B1	TEST
65-53875-7	LANDING LIGHT	MNG0496	ASR
65-53875-7	LANDING LIGHT	MNG0497	ASR
65-64960-3	MODULE ASSY - ANN LT	D00574	ASR
69-54600-3	CYLINDER ASSY - HYDR TRANSFER MAIN GEAR	DA2272	SV
861CAS3	ANGLE AIRFLOW SENSOR	265	SV
10-62024-4	NO BACK ASSY-SPEEDBRAKE	E2738	ASR
60B90038-4	FUEL ACTUATOR	99-171	ASR
69-14106-6	CYLINDER ASSY	DA1703	ASR
W92B	RUDDER ACTUATOR	0263	ASR
GM6425-E	ROTARY TRANSDUCER	1153	ASR
65C31116-3	VALVE MODULE	00828	ASR

65C16237-55	CARDFILE ASSY - TAKE OFF WARNING SYSTEM	D00736	ASR
10-60811-6	VALVE SELENOID THREE WAY	1188	ASR
65C26869-2	VALVE	FAH0216	ASR
VT-0306D-2	TRANSMITTER OIL/FUEL	20026	ASR
VT-0306D	FUEL TRANSMITTER	3460	ASR
E6412M27	AC MOTOR BRAKE ASSY.	890313	ASR
45-0083-7	RET. LANDING LIGHT	01Y	ASR
45-0083-7	RET. LANDING LIGHT	02Y	ASR
A800100-1	EXTINGUISHER	23	ASR
30-1401-3	LIGHT ASSY-STROBE	1607	ASR
45-0083-7	RET. LANDING LIGHT	027	SV
A61446-3	BYPASS VALVE	3685A	ASR
109486-6-1	DUCT BLEED AIR	P3548	ASR
A800100-1	EXTINGUISHER	0030	ASR
A9313205420005	MANIFOLD	MNG0083	ASR
315A1038-2	FUEL CONTRO BOX - L HOUSING	MNG0020	ASR
0091520200-2	VALVE ASSY-RSVR VENT	00539	ASR
65-44683-13	HOUSING ASSY	5573	ASR
65-825-029-00	FILTER ASSY	5360	ASR
7579078	RETURN MODULE FILTER	1489	ASR
C07202-2	SHAKER-COAXIAL CONTROL	6903	ASR
69-37308-555	PANEL	D00547	ASR
7583695	HYD. RETURN ASSY	788	ASR
7551901	FILTER	3129	ASR
316565	HYD RELIEF VALVE	38690	ASR
7579078	RETURN MODULE FILTER	1388	ASR
123266-2-1	VALVE ASSY-31-2 IN AIRCHECK	8110	ASR
69-37305-495	PANEL	D00591	ASR
65-45124-77	WHEEL ASSY - CAPT	MNG0036	ASR
28301-02	MASK AY	MNG0038	ASR
28301-02	MASK AY	MNG0039	ASR
C07202-2	SHAKER-COAXIAL CONTROL	6907	SV
69-37302-613	BASEPLATE ASSY	D00532	ASR
PDCI-IB-161	AIRSPEED SWITCH	3474	ASR
69-37310-394	SELCAL PANEL	D00528	ASR
214C50-2	SWITCH	J511	ASR
65-84107-3	RESERVOIR ASSY-BRG GREASE	MNG0005	ASR
69-37300-357	SELCAL PANEL	D00514	ASR
65C25529-6	SWITCH ASSY-STAB. TRIM CUTOUT CONTROL	8ET1846	ASR
65C33092-6	DOOR ASSY-FUEL ACCESS	2Q2005	ASR
40009-1	STATIC DRAIN	MNG0231	ASR
40009-1	STATIC DRAIN	MNG0232	ASR
40009-1	STATIC DRAIN	MNG0233	ASR
21SN04-121	OIL PRESSURE SWITCH	C105	ASR
CD-00526-1	AIR FILTER	A1039	ASR
123CH1A	DETECTOR	6110	ASR
214C40-1-110	PRESSURE SWITCH	549848	SV

10-60593-13	FILTER ASSY	1355	ASR
430M1	HORN	5	ASR
65C33147-7	DOOR ASSY-DRIPSTICK	3090	ASR
36024F23-6-0180	HOSE ASSY	MNG0041	ASR
36024F22-4-0110	HOSE ASSY	MNG0052	ASR
36024F23-6-0074	HOSE ASSY	MNG0054	ASR
36024F23-6-0160	HOSE ASSY	MNG0058	ASR
90G118-2	HYD PUMP PRESS. SW	5657	SV
BACR13CF2AB	RELAY	MNG0084	ASR
BACR13CF2AB	RELAY	MNG0155	ASR
BACR13CF2AB	RELAY	MNG0156	ASR
BACR13CF2AB	RELAY	MNG0188	ASR
941D335-2	CONTRACTOR	PZ3277B	ASR
941D335-2	CONTRACTOR	ZH9103B	ASR
56B17A6B	TEMP SENSOR	01158	ASR
31-1498-1	LIGHT ASSY	MNG0367	ASR
31-1498-1	LIGHT ASSY	MNG0368	ASR
732-11240-01	RESERVOIR PRESSURIZATION MODULE AIR FILTER	61-770	ASR
69-34206-9	LIGHT - MAP PILOT	MNG0029	ASR
10-0015-1	LIGHT WHEEL WELL	MNG0455	ASR
4559	LAMP	MNG0465	ASR
4559	LAMP	MNG0486	ASR
4559	LAMP	MNG0487	ASR
90G118-2	HYD PUMP PRESS. SW	4373	SV
941D335-2	CONTRACTOR	ZN1010B	ASR
E28180-10	PROTECT. BREATH EQ.	ARYK-0849	EXPIRED
E28180-10	PROTECT. BREATH EQ.	ARYK-0824	EXPIRED
E28180-10	PROTECT. BREATH EQ.	ARYK-0823	EXPIRED
2013-1A	BATTERY	78629	EXPIRED
2013-1A	BATTERY	77851	EXPIRED
2013-1A	BATTERY	86430	EXPIRED
2013-1A	BATTERY	103474	EXPIRED
2013-1A	BATTERY	86429	EXPIRED
2013-1A	BATTERY	86428	EXPIRED
7G110-5	SWITCH	661	ASR
81000-17501	MAP LIGHT ASSY	MNG0189	ASR
10-60522-60	MEASURING STICK	304	ASR
7G110-5	SWITCH	2833	ASR
7G110-5	SWITCH	2988	ASR
A8985-9	LIGHT AY	MNG0369	ASR
A8985-9	LIGHT AY	MNG0370	ASR
A8985-9	LIGHT AY	MNG0372	ASR
A8985-9	LIGHT AY	MNG0371	ASR
A8985-9	LIGHT AY	MNG0373	ASR
A8985-9	LIGHT AY	MNG0374	ASR
S3107-101	FIRST AID KIT	FA6AA010	ASR
7004-00	FIRST AID KIT	604093	ASR

802300-14	PBE SMOKE HOOD	105001143	EXPIRED
802300-14	PBE SMOKE HOOD	E08110294	EXPIRED
7G110-5	SWITCH	2978	ASR
7G110-5	SWITCH	2981	ASR
7G110-5	SWITCH	3005	ASR
65-46217-	MAIN WHEEL COVER	MNG0140	ASR
KD4L036	RELAY	MNG0157	ASR
E-311P	DC UNDER VOLTAGE	CH-124123	ASR
69B90118-16	SLEEVE	MNG0476	ASR
69B90118-16	SLEEVE	MNG0477	ASR
MS2415201	VOLTAGE COIL CONTACT	MNG0440	ASR
S65-5366-7L	ANTENNA	43070	NE
915F213-4	BUS PROT	WK2374B	SV
16007-045	VALVE AY-CHECK	TK-41	SV
624018-1	CABIN ZONE TEMP.	037C1536	TEST
4039893-903	VERTICAL SPEED IND.	94015479	SV
622-3890-020	TRANSCEIVER	5105	SV
65-54499-38	AURAL WARNING, M315	D02023	SV
69-37317-64	HYDR PUMP ASSMBLY	D00972	ASR
4039893-903	VERTICAL SPEED IND.	88122242	SV
792-6275-005	ADF CONTROL PANEL	6063	SV
10037-1000-0158	IND.-FUEL QUANTITY	128	SV
20041-0000-03	TRANSMITTER	3071H	SV
65-52819-25	DSWC	D01116	SV
211EDP1-3	EIS SECONDARY DISPLA	AB507/010	SV
2061-14-1	FLAP POSITION IND.	2960	SV
253884	SURFACE POS. IND.	09882081	SV
69202-300-3	HEAT EXCHANGER	12822	OH
4061100-901	COMPUTER-AIR DATA	98122342	SV
2-792-02	BATTERY CHARGER	3148	SV
5141-1-25	AUDIO CONTROL PANEL	394	ASR
10100C2F	MASK	MNG1	EXPIRED
05939-3	BALLAST		NE
05939-3	BALLAST		NE
05939-3	BALLAST		NE
05939-3	BALLAST		NE
69-37344-22	EFI/IRS MODULE	D00736	SV
941D339-1	TRANSFORMER PACKAGE	15720	SV
H321AKM1	STANBY INDICATOR	8193	SV
8901-274	C.I.T. SENSOR	WYG64472	US
69-73713-12	MODULE	D00678	ASR
DMN27-2	ANTENNA		ASR
DMN4-26	ANTENNA-LOCALIZER	523	ASR
DMN4-26	ANTENNA-LOCALIZER	1927	ASR
5141-1-25	AUDIO CONTROL PANEL	593	ASR
622-7080-001	ADF PANEL	179	OH
941D335-2	CONTRACTOR	TH8605	OH

941D335-2	CONTRACTOR	SN14672	OH
941D335-2	CONTRACTOR	YJ11508	OH
941D335-2	CONTRACTOR	NL13064	SV
941D335-2	CONTRACTOR	YN962	SV
AW2835AB05	DIFF. PRESSURE IND.	1079	SV
BPS7-3	BATTERY POWER SUPPLY	32859	SV
65-52818-9	AUTO SLAT COMPUTER	D01447	SV
65-52818-9	AUTO SLAT COMPUTER	D00899	SV
65-52818-9	AUTO SLAT COMPUTER	D01349	SV
65-52819-25	DSWC	D01381	SV
2-792-02	BATTERY CHARGER	178	SV
39B168-1B	STATIC INVERTER	625	SV
1-899-15	PROXIMITY SENSOR	106632	ASR
01-0770544-00	HORN	02674	ASR
861CAS3	ANGLE AIRFLOW SENSOR	01234	ASR
61-36-2	BALLAST		ASR
61-36-2	BALLAST		ASR
61-36-2	BALLAST		ASR
ST106AB	TRANSMITTER-PRESSURE	11810	OH
ST106AB	TRANSMITTER-PRESSURE	11236	OH
ST-107R	TRANSMITTER	9159A	US
31-1498-1	LIGHT ASSY	NA	ASR
31-1498-1	LIGHT ASSY	N-A	US
31-1498-1	LIGHT ASSY	N A	US
31-1498-1	LIGHT ASSY	NSN	US
S332A104-10	DUCT		NE
5701803	BALL SCREW ASSY	3960	SV
5701803	BALL SCREW ASSY	3941	SV
5702224	BALL NUT SCREW ASSY	WAAW5900	SV
07311P000-02	BALL SCREW ASSY	823B	SV
140N2022-1	VALVE-DRAIN		NS
65C27501-3	GEARBOX	10214	SV
69-14106-7	CYLINDER ASSY	2156	SV
65-63851-13	ACTUATOR	6743	SV
65C38059-12	ACTUATOR	WAAW5797	SV
7552355	PTU PRESSURE FILTER KIT	01387	OH
915F466-2	STATOR	9B19	OH
1552-002-9	PRESSURE REGULATOR	1975	SV
1732510	FILTER	W12140	SV
233145	SHUTOFF GATE	2428	SV
315A1016-3	STRUT DRUM CONT BOX	DCNDADCN10	SV
10-62090-30	SPEAKER	722	ASR
69-37325-129	MODULE	D01157	ASR
CGAB1400-00	SMOKE DECT.	495	ASR
CGAB1400-00	SMOKE DECT.	5545	ASR
CGAB1400-00	SMOKE DECT.	423	ASR
10-62047-5	SENSOR	00528	ASR

10-60735-2	OXY PRESS IND	08883328	ASR
10-60757-23	INDICATOR	88082125	ASR
10-60757-24	INDICATOR	90032715	ASR
10-60757-25	INDICATOR		ASR
10-60757-27	INDICATOR		ASR
10-60757-27	INDICATOR		ASR
123CH1A	DETECTOR	2374	ASR
152LMA23	TEMPERATURE IND.	K185	ASR
162BL801	FUEL TEMP. IND.	2118	ASR
10037-1000-0158	IND.-FUEL QUANTITY	134	ASR
10037-1000-0158	IND.-FUEL QUANTITY	102	ASR
10037-1000-0158	IND.-FUEL QUANTITY	115	ASR
214C50-2	SWITCH	L446	ASR
941D335-2	CONTRACTOR	YJ11575	ASR
941D335-2	CONTRACTOR	ZH9108	ASR
S250N104-4	XMTR	BS8825H48	ASR
S250N104-4	XMTR	BS8825H06	ASR
A419-055335-15	RELAY		ASR
SRLOC7EM	IND.HYDR BRAKE PRES.	1669	ASR
61-36-2	BALLAST		ASR
65C33409-1	SWITCH	D00078	ASR
10-60757-28	INDICATOR	88120516	ASR
9124-8073	RELAY		ASR
473597-5	SMOKE DETECTOR	347	BER
391046-05138	TRANSMITTER	4092	ASR
71234	HAND-PUMP	H5156G	ASR
906D896-3	TRANSFORMER	XL7352	ASR
906D896-3	TRANSFORMER	SJ5993	ASR
R6200M3-11	ACTUATOR	880608	ASR
S41422	ANTENNA		ASR
63169	MOTOR AY	235712A	ASR
65-44691-5	MODULAR ASSY	4274	ASR
65C26864-2	ACTUATOR	2271	ASR
65C26864-2	ACTUATOR	2217	ASR
69-54600-4	CYLINDER ASSY.	3344	ASR
123CH1A	DETECTOR	3330	ASR
204050-11	COOLING TURBINE	13-5825	ASR
204050-11	COOLING TURBINE	389629-6	ASR
7551901	FILTER	3718	ASR
R6200M3-11	ACTUATOR	821013	ASR
65-44691-5	MODULAR ASSY	4364	ASR
65-44691-6	MODULAR ASSY	1784	ASR
65-44981-5	MODULAR PACKAGE AY	2200	ASR
65C26864-2	ACTUATOR	2203	ASR
65C26864-2	ACTUATOR	2227	ASR
65C26869-2	VALVE	FAH0599	ASR
10-60508-2	CHECK VALVE		ASR

732-11240-02	MODULAR ASSY	78-305	ASR
831100-1	FUEL PUMP	10119A	ASR
831100-2	FUEL PUMP	11324A	ASR
65-44561-15	ACTUATOR	5693	ASR
65-44991-3	PACKAGE ASSY	1697	ASR
31040	VALVE, EQUI COOLING	6	US
2670150-5	SHUTOFF VALVE	1830	ASR
398116-1-1	VALVE	4135	ASR
700-1303-001	BOX	NSN1	ASR
941D335-2	CONTRACTOR	Y110409	ASR
941D335-2	CONTRACTOR	YJ11514	ASR
941D335-2	CONTRACTOR	PY3087M	ASR
S250N104-4	XMTR	B58822E89	ASR
65-68945-8	HORN FIRE WARN.		ASR
6577-1	FAN-VANEAXIAL	10358	ASR
6577-1	FAN-VANEAXIAL	10525	ASR
6577-1	FAN-VANEAXIAL	123	ASR
10-61224-6	TRANSFORMER	OJ3813	ASR
69-37352-30	MODULE	D00983	ASR
721RAA2	SWITCH		ASR
721RAA2	SWITCH		ASR
1-899-15	PROXIMITY SENSOR	98275	ASR
1-899-15	PROXIMITY SENSOR	NSN2	ASR
1-899-15	PROXIMITY SENSOR	NSN3	ASR
1-899-15	PROXIMITY SENSOR	NSN4	ASR
1-899-15	PROXIMITY SENSOR	NSN5	ASR
1-899-15	PROXIMITY SENSOR	NSN6	ASR
1-899-15	PROXIMITY SENSOR	NSN7	ASR
436-2	DETECTOR	7078	ASR
021169	FAN	PR0772	ASR
D434-56-001	ANNUCIATOR	1444/04-91	ASR
D434-56-001	ANNUCIATOR	1792/01-92	ASR
S250N104-4	XMTR	B58822F6	ASR
ST-107R	TRANSMITTER	10710A	ASR
60B00303-103	DIGI ELEC CHRONOMETE	452	ASR
S250N104-5	XMTR	3828C98	ASR
831100-2	FUEL PUMP	11322A	ASR
831100-2	FUEL PUMP	11333A	ASR
30-0906-105	RECOGNITION LIGHT	533	ASR
4039893-902	VERTICAL SPEED IND	D00394	ASR
3810056-105	VALVE	716	ASR
3810056-106	VALVE, T/R CONTROL	8272	ASR
45-0083-3	RET. LANDING LIGHT	5113G	ASR
65-52817-9	INTERPHONE AMPLIFIER	15159A	ASR
743-0193-008	UNIT	15147A	ASR
2-541501-1A	SNUBBER ASSY	W5267	ASR
316565	HYD RELIEF VALVE		ASR

1U1065-2	COMPENSATOR	NSN	ASR
1U1065-2	COMPENSATOR	4844	ASR
21C1-3-22	SWITCH	1431	ASR
7591722-101	HYD ASSY	2232	ASR
H504B	TRANSMITTER	2-2306	ASR
840002-074	ACOUSTIC FILTER	S.C. 2158	ASR
840002-074	ACOUSTIC FILTER	90012793	ASR
65-44981-5	MODULAR PACKAGE AY	2386	ASR
65C25540-1	TRANSMITTER		ASR
65C26859-1	BRAKE FEEL ACTUATOR	053C12048	ASR
4039893-903	VERTICAL SPEED IND.	NA	ASR
2057-01-1	IND SERVO ALTITUDE		ASR
10C10F	SWITCH		NS
607690-2	ELT		SV
S250N104-5	XMTR		ASR
65-55583-118	RETAINER		NE
522-1837-000	ADF ANTENNA	8559	ASR
522-1837-000	ADF ANTENNA	8577	ASR
332A1311-20	STAGE 9 DUCT		SV
65-44551-6	ACTUATOR	1561	ASR
65-44551-7	L/E FLAP ACTUATOR	5034	ASR
65-44551-7	L/E FLAP ACTUATOR	5024	ASR
65-44610-4	NLG HYD.ACTUATOR AS.	SHL171	ASR
65-44761-21	POWER CONT UNIT	7517A	ASR
65C38059-14	ACTUATOR	1250	ASR
1FA14012-6	ACTUATOR ASSY-FORG.	FAH2362	ASR
3200-19	TOILET PUMP	5-469	ASR
801240-3	FAN	119-855	ASR
645405-1	FAN-RECIRCULATION	71-1774	ASR
711002-4	PRESSURE CTRL. PANEL	GD54048	ASR
392678-1-1	PLG PRESS	2	ASR
9375M10G03	MANIFOLD		NS
S314A201-4	ROD	3410	ASR
65-18621-5	PLATE		NS
65-46451-69	SEAL		NS
65-47951Y5	PLATE		NS
7825223	BALLSCREW	0042	US
332A1301-1	STARTER		OH
3-1438-1	NOSE WHEEL ASSY B737	1174	ASR
3-1438-1	NOSE WHEEL ASSY B737	2573/2573	REP
APS01325	MAIN TIRE	Y06NB041	US
APS01207	TIRE	112FT096	US
APS01207	TIRE	413FT053	US
APS01207	TIRE	411FT018	US
2607825-1	NOSE WHEEL ASSEMBLY	2885	ASR
3-1438-1	NOSE WHEEL ASSY B737	1366	ASR
315A1001-557	T/R COWL	N/A	ASR

315A1001-5586	T/R COWL	N/A	ASR
315A1001-555C	T/R COWL	N/A	ASR